## **HWH CORPORATION**

**MOSCOW, IOWA 52760** 

### ITEM MASTER NAMING CONVENTION

# DESCRIPTION ABBREVIATIONS (PAGE 1 of 2) FOR DRAWINGS AND NCR PART DESCRIPTIONS

**GENERAL RULE:** Only use abbreviations in our Technical Manuals if you absolutely can't fit the entire word.

ACCESSORY (General)	ACC	HARDWARE	HDWE
ACCURACY (Material Spec's)		HARNESS	
ADAPTER		HEX HEAD CAP SCREW	HHCS
ADD ON		HIGH PRESSURE	
AIR		HOT ROLL	
		HYDRAULIC	
AIR SEAL	_ A/S		
ALUMINUM	_ AL	(Unless a Leveling System, then)	) [
AUTOMATIC	AU	INDIED DIAMETED	
BALL 0175B	50	INNER DIAMETER	
BALL SIZER		INTERFACE	
BARREL		INTERRUPT	
BLACK		INSERT	INS
BLADE			
BLANK		KICK-DOWN	. K
BORING BARS	BB		
BRACKET	BRKT	JOYSTICK-CONTROLLED	J
BRUSH			
BUNDLE	BDL	LANDING GEAR	LG
BUSHING	BUSH	LEFT HAND	
BUZZER		LEVER-CONTROLLED	. <u>-</u>
	_ 52	LIMIT SWITCH	. <u>-</u>
CABLE	CBI	LIMIT SWITCHLOCKING ROD GUIDE	L_SW
CENTRAL GROUND	COL	LOCKING ROD GOIDE	LKG
		LOCKS	. L
CHANNEL (Non Material)		MACHINED	
COLD DRAWN		MACHINED	
COLLET	COL	MALE & FEMALE	. MF
COMPRESSOR		MALE FITTING	
COMPRESSION		MANIFOLD	
COMPUTER-CONTROLLED		MASTER	MSTR
CONCENTRICITY PIN	_ CP	MASTER RELAY	MR
CUT-OFF TOOLS	COT	MEDIUM PRESSURE	MP
CYLINDER		MOUNTING	MTG
DIE	DIE	NO LOOM	NL
DRAWN GROUND & POLISHED	DG&P	NOZZLE	NOZL
DRAWN OVER MANDREL	DOM		
DRILL		OUTER DIAMETER	OD
DUMP			
	. 5	PARK BRAKE	PR
EXTRUSION	FYTR	PARTIAL	
		PIGTAIL	
EXTENSION	_ =	PILOT DUMP	. FUIL
FACING	E4.0E		
FACING		PIVOT	
FIFTH WHEEL		PLATED	
FIXED		POWER	PWR
FORE & AFT SPRINGS		PRESSURE SWITCH	
FRONT AIR	F/A	(Unless for Jacks, then)	
		PROFILING TOOL	
GEN SLIDE	GEN *except for Western	PUMP	PMP
	then GEN SLIDE	PUMP RELAY	. PR
GROOVING BARS		PUMP RELAY PUNCH	

### **HWH CORPORATION**

MOSCOW, IOWA 52760

#### ITEM MASTER NAMING CONVENTION

# DESCRIPTION ABBREVIATIONS (PAGE 2 of 2) FOR DRAWINGS AND NCR PART DESCRIPTIONS

REAR AIRREVERSING MOTORRIGHT HANDROOM EXTENSIONROUND	RVM RH RE
SANDVIK	SCR SNSG SHK SH S/S SPEC SS S
TAG	TL TD THR T TRANS
VALVEVELOCITY VALVE	VLV VV
WARNING	
1999 FORD 53 CHASSIS	99F53
2POINT	2PT
3POINT	3PT
4POINT	4PT

**NOTE:** NO INCHES ON HARNESS LENGTHS EXAMPLE: 5'5" = 5'

5'6" = 6'

#### **CALLOUT EXAMPLE FOR HARNESSES:**

HARN F/A XX' SYSTEM TYPE HARN BDL/D/TG XX' SYSTEM TYPE HARN 1SW-BOX HARN 1RE BOX-PMP